


TIMKEN

Where You Turn

**How do you rate on bearing adjustment?
Do you know what setting you're actually achieving?**

Accurately measure and adjust to obtain the recommended wheel bearing end play or axial clearance using the Timken End Play Gauge.



The end play gauge, which is adjustable and universal, is designed to mount on the wheel ends of all popular Australian heavy duty trucks and trailers.



End Play Gauge



The Timken End Play Gauge (BK211) ensures accurate bearing setting measurement time after time, allowing precise adjustment within the manufacturers recommendations, maximising wheel bearing life. Here are some of the reasons why?

- Adapts to any wheel end
- Ergonomic handles
- Self contained in durable case
- Allows rigid fixing of indicator
- Eliminates guess work
- Highly reliable
- Reduces errors

Contact of the dial indicator tip with the axle end is improved through unique magnetic adaptor cap, eliminating errors and improving precision.

For more product and performance information on Timken End Play Gauge contact your

TIMKEN Sales Representative
or call the Customer Support Centre
on 1800 060 345

Part Number	Description
BK211	Timken End Play Gauge

Designed in Australia for Australian conditions.